











RETROFIT KITS

FOR VARIABLE VOLUME FLOWS OR V_{MIN}/V_{MAX} SWITCHING IN ROOM AIR CONDITIONING SYSTEMS

Actuators and installation accessories for mechanical self-powered CAV controllers Type EN, RN, or VFC, and flow adjustment dampers Type VFR

- Parts kits for easy retrofit
- Potentiometer or mechanical stops
 Supply voltage 24 V AC/DC or 230 V AC
 Control input signal: Signal voltage 0 10 V for modulating
- actuators • Control input signal: 1-wire control or 2-wire control (3-point) for
- Positive lock connection with CAV controller or flow adjustment
- damper

Optional accessories for Types RN and EN

Auxiliary switch with adjustable switching points, for example for

Application

Application

Parts kits for the retrofit of mechanical self-powered volume flow controllers or flow adjustment dampers with actuators.

CAV controllers Type EN or RN, as well as for VFC

- Min/Max switching of volume flow setpoint values
- Variable adjustment of volume flow rate setpoints

Flow adjustment dampers Type VFR

• Min/Max change of the damper blade position

Description

Parts and characteristics

- Damper blade can take various positions
 Mechanical stops or potentiometers (only for Types VFC and VFR) to set the volume flow rates
 Supply voltage 24 V AC/DC or 230 V AC
- Switching between setpoint values or signal voltage range0 10 V DC

ТЕХНИЧЕСКА ИНФОРМАЦИЯ

Actuators for volume flow controllers Type RN or EN

Part number	Quality	Supply voltage	Model	Identical to attachment
NR-VAV-B50	Min/Max switching, mechanical stops	24 V AC/DC	LMA24-F	B50
NR-VAV-B60	Min/Max switching, mechanical stops	230 V AC	LMA230-F	B60
NR-VAV-B70	Variable adjustment, mechanical stops	24 V AC/DC	LMA24-SR-F	B70
NR-VAV-S2	Auxiliary switch		S2A	B*2
NR-VAV-RNMAT	Installation accessories for RN			
NR-VAV-ENMAT	Installation accessories for EN			

Installation accessories for CAV controllers Type EN or RN are to be ordered separately

Retrofit kits for min/max switching or for the modulating adjustment of mechanical self-powered volume flow controllers in ventilation and air conditioning systems.

Retrofit kits for EN, RN, VFC, VFR

ſ

Betrofit kit For Types RN and EN NR-VAV-B50 Retrofit actuator for min/max switching, identical to attachment B50 NR-VAV-B60 Retrofit actuator for min/max switching, identical to attachment B60 NR-VAV-B70 Retrofit actuator for variable adjustment, identical to attachment B70 NR-VAV-B70 Retrofit actuator for variable adjustment, identical to attachment B70 NR-VAV-S2 Retrofit actuator for variable adjustment, identical to attachment B70 NR-VAV-S1 Installation accessories for RN NR-VAV-ENMAT Installation accessories for EN For Types VFC and VFR NR-VAV-E01 Retrofit actuator for min/max switching, identical to attachment E01 NR-VAV-E02 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M01 Retrofit actuator for variable adjustment, identical to attachment E03 NR-VAV-M01 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M01 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M01 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M01 Retrofit actuator for min/max switching, identical to attachment M01 NR-VAV-M01 Retrofit actuator for min/max switching, identical to attachment M01 NR-VAV-M01 Retrofit actuator for min/max switching, identical to attachment M01	NR-VAV-B50				
For Types RN and EN NR-VAV-B50 Retrofit actuator for min/max switching, identical to attachment B50 NR-VAV-B60 Retrofit actuator for min/max switching, identical to attachment B50 NR-VAV-B70 Retrofit actuator for variable adjustment, identical to attachment B70 NR-VAV-B70 Retrofit actuator for variable adjustment, identical to attachment B70 NR-VAV-S2 Retrofit actuator for variable adjustment, identical to attachment B70 NR-VAV-RNMAT Installation accessories for RN NR-VAV-F01 Retrofit actuator for min/max switching, identical to attachment E01 NR-VAV-E01 Retrofit actuator for min/max switching, identical to attachment E02 NR-VAV-E01 Retrofit actuator for min/max switching, identical to attachment E02 NR-VAV-E03 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-E04 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-E03 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-W01 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M01 Retrofit actuator for min/max switching, identical to attachment M01 NR-VAV-M02 Retrofit actuator for min/max switching, identical to attachment M01		di di			
NR-VAV-B50 Retrofit actuator for min/max switching, identical to attachment B50 NR-VAV-B60 Retrofit actuator for min/max switching, identical to attachment B60 NR-VAV-B70 Retrofit actuator for win/max switching, identical to attachment B70 NR-VAV-B70 Retrofit actuator for win/max switching, identical to attachment B70 NR-VAV-B7 Retrofit actuator for win/max switching, identical to attachment B70 NR-VAV-RNMAT Installation accessories for RN NR-VAV-ENMAT Installation accessories for EN For Types VFC and VFR NR-VAV-E01 Retrofit actuator for min/max switching, identical to attachment E01 NR-VAV-E02 Retrofit actuator for min/max switching, identical to attachment E02 NR-VAV-E03 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M01 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M02 Retrofit actuator for min/max switching, identical to attachment M01	1 Retrofit kit				
identical to attachment B50 NR-VAV-B60 Retrofit actuator for min/max switching, identical to attachment B60 NR-VAV-B70 Retrofit actuator for variable adjustment, identical to attachment B70 NR-VAV-S2 Retrofit auxiliary switch, identical to attachment B72 NR-VAV-RNMAT Installation accessories for FIN NR-VAV-E01 Retrofit actuator for min/max switching, identical to attachment E01 NR-VAV-E02 Retrofit actuator for min/max switching, identical to attachment E02 NR-VAV-E03 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-E03 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-E03 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M01 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M02 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M04 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M04 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M04 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M04 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M04 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M04 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M04 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M05 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M05 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M05 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M05 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M05 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M05 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M05 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M05 Retrofit actuator for min/max switching, identical to	For Types	RN and EN			
identical to attachment B60 NR-VAV-B70 Retrofit actuator for variable adjustment, identical to attachment B70 NR-VAV-S2 Retrofit auxiliary switch, identical to attachment B*2 NR-VAV-ENIMAT Installation accessories for EN NR-VAV-ENIMAT Installation accessories for EN For Types VFC and VFR NR-VAV-E01 Retrofit actuator for min/max switching, identical to attachment E01 NR-VAV-E02 Retrofit actuator for min/max switching, identical to attachment E02 NR-VAV-E03 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M01 Retrofit actuator for min/max switching, identical to attachment M01 NR-VAV-M02 Retrofit actuator for min/max switching,	NR-VAV-B50				
identical to attachment B70 NR-VAV-S2 Retrofit auxiliary switch, identical to attachment B*2 NR-VAV-RNMAT Installation accessories for RN NR-VAV-ENMAT Installation accessories for EN For Types VFC and VFR NR-VAV-E01 Retrofit actuator for min/max switching, identical to attachment E01 NR-VAV-E02 Retrofit actuator for variable adjustment, identical to attachment E03 NR-VAV-M01 Retrofit actuator for min/max switching, identical to attachment M01 NR-VAV-M02 Retrofit actuator for min/max switching, identical to attachment M01 NR-VAV-M02 Retrofit actuator for min/max switching, identical to attachment M01	NR-VAV-B60				
attachment B*2 NR-VAV-RNMAT Installation accessories for RN NR-VAV-ENMAT Installation accessories for RN For Types VFC and VFR NR-VAV-E01 Retrofit actuator for min/max switching, identical to attachment E01 NR-VAV-E02 Retrofit actuator for variable adjustment, identical to attachment E03 NR-VAV-M01 Retrofit actuator for min/max switching, identical to attachment M01 NR-VAV-M02 Retrofit actuator for min/max switching, identical to attachment M01 NR-VAV-M02 Retrofit actuator for min/max switching, identical to attachment M01	NR-VAV-B70				
NR-VAV-ENMAT Installation accessories for EN For Types VFC and VFR NR-VAV-E01 Retrofit actuator for min/max switching, identical to attachment E01 NR-VAV-E02 Retrofit actuator for min/max switching, identical to attachment E02 NR-VAV-E03 Retrofit actuator for variable adjustment, identical to attachment E03 NR-VAV-M01 Retrofit actuator for min/max switching, identical to attachment M01 NR-VAV-M02 Retrofit actuator for min/max switching, identical to attachment M01	NR-VAV-S2				
For Types VFC and VFR NR-VAV-E01 Retrofit actuator for min/max switching, identical to attachment E01 NR-VAV-E02 Retrofit actuator for min/max switching, identical to attachment E02 NR-VAV-E03 Retrofit actuator for variable adjustment, identical to attachment E03 NR-VAV-M01 Retrofit actuator for min/max switching, identical to attachment M01 NR-VAV-M02 Retrofit actuator for min/max switching, identical to attachment M01	NR-VAV-RNMAT	Installation accessories for RN			
NR-VAV-E01 Retrofit actuator for min/max switching, identical to attachment E01 NR-VAV-E02 Retrofit actuator for min/max switching, identical to attachment E02 NR-VAV-E03 Retrofit actuator for variable adjustment, identical to attachment E03 NR-VAV-M01 Retrofit actuator for min/max switching, identical to attachment E03 NR-VAV-M02 Retrofit actuator for min/max switching, identical to attachment M01 NR-VAV-M02 Retrofit actuator for min/max switching, identical to attachment M01	NR-VAV-ENMAT	Installation accessories for EN			
identical to attachment E01 NR-VAV-E02 Retrofit actuator for min/max switching, identical to attachment E02 NR-VAV-E03 Retrofit actuator for variable adjustment, identical to attachment E03 NR-VAV-M01 Retrofit actuator for min/max switching, identical to attachment M01 NR-VAV-M02 Retrofit actuator for min/max switching,	For Types	VFC and VFR			
identical to attachment E02 NR-VAV-E03 Retrofit actuator for variable adjustment, identical to attachment E03 NR-VAV-M01 Retrofit actuator for min/max switching, identical to attachment M01 NR-VAV-M02 Retrofit actuator for min/max switching,	NR-VAV-E01				
identical to attachment E03 NR-VAV-M01 Retrofit actuator for min/max switching, identical to attachment M01 NR-VAV-M02 Retrofit actuator for min/max switching,	NR-VAV-E02				
identical to attachment M01 NR-VAV-M02 Retrofit actuator for min/max switching,	NR-VAV-E03				
	NR-VAV-M01				
identicanto attachment Moz	NR-VAV-M02	Retrofit actuator for min/max switching, identical to attachment M02			
